

Instruction

T007K009

Concrete Pendants - Stars



Material Used	Article Number	Quantity
Casting Mould - Christmas, 1 mould, 4 motives, size approx. 60 - 80 mm, approx. 10 - 15 mm high, material required: approx. 100 g jewellery-concrete	620765	1
Casting Mould - Snow Flakes, 1 mould, 5 motives, size approx. 100 - 35 mm, approx. 5 - 8 mm high, material required: approx. 200 g jewellery-concrete	620754	1
Fine Concrete for Jewellery, 500 g	608792	1
Fine Concrete for Jewellery, 1500 g	619692	alternatively
Fine Concrete for Jewellery, 3000 g	608806	alternatively
Release Agent - Formestone 100 ml	480666	1
Formalate - Latex Casting Compound, 300 ml	572109	1
OPITEC Dowels - Economy Pack, approx. \varnothing 6 x 30 mm, 200 pieces	602877	1
Deco & Lifestyle Hobby Paint 230 ml, white	446228	1
Deco & Lifestyle Hobby Paint 230 ml, silver	446561	1
Creall® Dacta Color Poster Paint, 500 ml, white	446686	alternatively
Creall® Dacta Color Poster Paint, 500 ml, silver	446848	alternatively
Deco Thread, approx. \varnothing 2 mm x 100 m, white/black	580241	1
Decorative Stitching Ribbon, approx. 2 m x 10 mm, silver grey	809246	1
Recommended Tools		
Stencil Dabbers approx. \varnothing 15/20/30/45 mm, set of 4	494232	1
STEINEL® Glue Gun Gluematic 3002	319101	1
Glue Sticks, approx. \varnothing 11 x 200 mm, 25 pieces	301139	1
Tools Required		
Working pad, scissors, kitchen roll, round and bristle brush, measuring cup (or scales), mixing bowl, whisk (or spatula), hot glue gun with glue sticks		

1. Generously apply Formestone to the interior surface of the casting mould (according to product instruction) and allow to dry.
2. Insert the dowels several times into Formalate casting compound (according to product instruction), allow to dry.
3. Glue dowels as place holders (for cord and bow) to the interior surfaces of the casting mould (glue gun).
4. Mix fine concrete according to product instruction.
5. Completely fill up the casting mould.
6. Allow to harden for 1 - 2 days.
7. Remove place holders for bow/cord (dowels).
8. Remove cast concrete stars from the mould.
9. Allow residual moisture to escape from the concrete.
10. Apply paint with dabbers or brush and allow to dry.
11. Cut ribbon and cord to desired size.
12. Lead ribbon or cord through the hole of the concrete pendant.
13. Close with bow or knot.

*Have fun creating and enjoy!
Your OPITEC Creative Team!*